



PFADT

RACE ENGINEERING

888-972-2464

Camaro Sport Sway Bar Instructions

This sway bar set is a direct factory replacement for the stock bars. Please follow the factory service procedure for removal and installation.

Hints and Tips:

- the front swaybar should be removed out the passenger side of the car
- the right front wheel should be removed and the car must be lifted
- the engine does not have to be lifted to install the front bar
- the rear bar can be removed and re-installed without removing any other factory components
- generously lube the bushings prior to installation

Torque Specs:

- front swaybar bracket nuts - 15 ft-lb
- rear swaybar bracket bolts - 15 ft-lb
- endlink nuts (front and rear) - 22 ft-lb