

MAKE A HANDS-FREE CALL

Muting/unmuting calls:

If the inside of your vehicle becomes noisy, you can mute a call at any time.

Muting a call using the 'Mute' command:

- 1. Press the Push to Talk button
- 2. Your system will respond with a "Ready" message followed by a tone
- 3. Clearly say "Mute call"
- 4. Your system responds with a "Call muted" message and mutes the call

Unmuting a call using the 'Unmute' command:

- 1. Press the Push to Talk button
- 2. Your system will respond with a "Ready" message followed by a tone
- 3. Clearly say "Mute Call"
- 4. Your system responds with a "Resuming call" message and unmutes the call

Bluetooth Controls

€ № Push To Talk

>>> V Phone On Hook