

CAMARO SUSPENSION BOLT AND NUT SIZE

FRONT SUSPENSION

PEDDERS CAMBER ALLEN ADJUSTER	5MM ALLEN
TIE RODS TO KNUCKLE	18MM
TIE ROD BALLJOINT END	8MM
OE SWAY BAR END LINKS	15MM/7MM END
PEDDERS SWAY BAR END LINKS	19MM/5MM ALLEN
PEDDERS END LINK NOTCH ON BALLSTUD	13MM
PEDDERS END LINK INSIDE ON BALLSTUD	14MM
CONTROL ARM BALLJOINT	21MM
RADIUS ROD BALLJOINT	21MM
RADIUS ROD BALL JOINT END	10MM
OE RADIUS ROD BOLT	21MM
PEDDERS CASTER ECCENTRIC BOLT/NUT	22MM
SWAY BAR MOUNT BOLTS	13MM
STEERING GEAR MOUNT BOLTS	18MM
UPPER STRUT MOUNT NUT	24MM
OE UPPER STRUT SHAFT TORX	45 TORX
UPPER STRUT NUT	24MM
CLEVIS OR STRUT TO KNUCKLE BOLT AND NUT	24MM
STRUT TO BRAKE HOSE BOLT	10MM
PEDDERS XA STRUT KNOB ADJUSTER NUT	19MM

REAR SUSPENSION

LOWER SHOCK MOUNT	21MM
OE CAMBER ECCENTRIC	21MM
PEDDERS CAMBER ECCENTRIC	22MM
OUTER TOE LINK TO KNUCKLE	18MM
OE TOE LINK ECCENTRIC	21MM
PEDDERS TOE LINK ECCENTRIC	22MM
LOWER CONTROL ARM OUTER TO KNUCKLE	18MM
TRAILING ARM	18MM
UPPER STRUT MOUNT BOLTS (4)	15MM
UPPER STRUT NUT	18MM/45 TORX
UPPER PIVOT FOR CONTROL ARM	21MM
PEDDERS XA UPPER STRUT NUT	17MM/5MM ALLEN
UPPER REAR BUSHING BOLT	21MM
UPPER REAR BUSHING BRACKET BOLTS	18MM
OE SWAY BAR END LINK	15MM/ 5MM ALLEN
PEDDERS SWAY BAR END LINKS	19MM/5MM ALLEN
PEDDERS END LINK NOTCH ON BALLSTUD	13MM
PEDDERS END LINK INSIDE ON BALLSTUD	14MM
SWAY BAR MOUNTING BUSHING BRACKET BOLT	13MM
REAR DIFFERENTIAL BUSHING MOUNT BOLTS	18MM
DRIVESHAFT MOUNTING BOLTS TO DIFF	18MM